




















Stecker			
TYP ZŁĄCZ	Rysunek GNIAZDA	Wtyczka do gniazda	OPIS (nume
BL			GND-6 K-5 L-8 +12V-7
	Stecker Kabelbaum von vorn		

ST			GND-1 K-3 L-2 +12V-4
			GND-2 K-4 L-3 +12V-1
TR			GND-6 K-3 L-4 +12V-7
	Stecker Kabelbaum von vorn		

Typ	Gassteuergerät
BL	<b>AC</b> STAG 100, 150, XL <b>AG</b> RAZMUS, SIROCCO <b>AGIS</b> CAN, OBD <b>APROJEKT</b> ROXI <b>BIGAS</b> ELC '92, ELC PEGASO, SGIS, SGIS N <b>CAR-GAS</b> SOLARIS <b>D.T. GAS</b> DATEC BASIC, DATEC SUPER, GAS-TECH <b>ELPIGAZ</b> LEONARDO, MILENIUM, NICOLAUS/2004, STELLA/ ELIZA, VOILA PLUS <b>EMMEGAS</b> ICS-03 <b>ESGI</b> ESGI 2, ESGI 1 <b>EUREKA</b> EUREKA (sekwencyjny wtrysk gazu) <b>EUROPEGAS</b> OSCAR, OSCAR N, VECTOR <b>KING</b> KING <b>KME</b> AKME, BINGO, BINGO M, BINGO S, DIEGO, DIEGO G3 <b>LANDI RENZO</b> LAMBDA CONTROL SYSTEM A/1-V05-ER, BLuE <b>LECHO</b> AGNES, MAXI-LAMBDA <b>LO.GAS</b> LO.GAS <b>OMVL</b> DREAM XXI N <b>PROTEC DIGITAL</b> ORION <b>ROMANO</b> RIS, RISN <b>TAMONA</b> PROGAS <b>TARTARINI</b> Sequential = Black Ecu <b>V-TEC</b> V-TEC <b>VERSUS</b> VERSUS <b>ZAVOLI</b> ALISEI N, ZAVOLI N, REGAL
ST	<b>AC</b> 4GAS, STAG 200, STAG 300, STAG 300 PLUS, STAG 300 PREMIUM, STAG 4, STAG XL, VECTOR <b>KME</b> BINGO, BINGO M, BINGO S, DIEGO, DIEGO G3, DIEGO LS, NEVO <b>ESGI</b> ESGI 2 <b>LOVATO</b> FAST, SMART <b>LPGTECH</b> tech-100, tech-200, tech-300, tech-500 <b>IC</b> 4-GAS
	Steffanelli (nach meiner Recherche per Verkaufsangebot für Adapterkabel)
TR	<b>JUNIOR LAMBDA CONTROL</b> JUNIOR LAMBDA CONTROL <b>TARTARINI</b> ETAGAS sekwencyjny, TEC 97, TEC 99c, TEC 99 PRO, SFI

Stecker			
ZT			GND-4 K-2 L-3 +12V-1
OM			GND-1 K-2 L-3 +12V-4
LV			- Lovato (Lov-Eco2), Stecker Kabelbaum von vorn
JT			Stecker Kabelbaum von vorn
AT		In Abwesenheit von Kommunikation drehen Sie den Stecker nicht	+12V[grün] GND[gelb] L[schwarz] K[braun]
LN			- Les 98 (Landi). Stecker Kabelbaum von vorn

Typ	Gassteuergerät
ZT	<b>AG</b> ZENIT JZ-2005/2009, COMPACT <b>AUTOGAS ITALIA (AI)</b> EASYJET, Dreamjet <b>AUTRONIC</b> MISTRAL <b>Emmegas</b> ICS-03, ECU-07 <b>Poliauto</b> Sequential
OM	<b>LANDI RENZO</b> IGS, LCS/2, LCSA1/05, LCSE, Omegas <b>AEB</b> King
LV	<b>LOVATO</b> LOV-ECO, LOV-ECO PRO
JT	<b>BRC</b> JUST JUNIOR
AT	<b>AUTRONIC</b> A-MON, AL-700, AL720/p, AL-800, AL820
LN	<b>LANDI</b> LES 01, LES 98, LES 98A, LES 99, LIS